



VJAZD A VÝJAZD  
z úrovně 1.PP

M1  
M2  
M3  
M4  
M5

40 2500 42 2500 43 2500 44 2500 45 2500 46 2500 47 2500 48 2500 49 2500 50 2500 51 2500 52 2500 53 2500 54 2500 55 2500 56 2500 57 2400

26 2500 27 2500 28 2500 29 2500 30 2500 31 2500 32 2500 33 3500 34 2500 35 2500 36 2500 37 2500 38 2500 39 2400

16 2500 17 2500 18 2500 19 3500 20 2400 21 2500 22 2500 23 2500 24 2500 25 2400

1 2500 2 2500 3 2500 4 2500 5 2500 6 2500 7 2500 8 2500 9 2500 10 2500 11 2500 12 2500 13 2500 14 2500 15 2400